





SOPHIA TOUCHLESS SOLUTIONS Software Update

Units equipped with Cafecta Motherboard

Step 1 - Software Update




Make sure the machine is internet-connected.

1. Access Service mode.
2. In the System tab, select the Software Update subtab.
3. Press on the “Refresh” button to access the latest update available.
4. Press on the “Download” button.
5. Once the update is downloaded, press on the “Update now” button in the Download Status (a yellow pop-up window will appear).
6. Wait for the update process to complete.
7. Once the update is completed press on the “Restart” button and wait for the machine to reboot.



Step 2 - Activate Sophia Touchless Solutions

1. Access Service mode.
2. In the System tab, under the System 1 subtab, enable the “Touchless Option” toggle bar.
3. Click on the “Save” button and exit Service mode.



SOPHIA TOUCHLESS SOLUTIONS

A QR code will be displayed on the selection screen and you will be able to order without ever touching the screen.